

RVLF

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70

Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Motor Controllers

AC Variable Frequency Drives

Type Variflex³ RVLF Advance



RVLF

- AC variable frequency drive for use with AC induction motors
- V/F + Sensorless Vector (SLV)
- Input voltage ranges: 100-120V, 200-240V, 380-480V
- Conforms to EMC standard EN 61800-3
- PTC input provide motor temperature protection
- PID regulation function available on board
- Built-in Class A filter
- Panel mounting (optional DIN-rail accessory)
- Built-in Modbus and BACNET
- Optional communication interface modules for Profibus/DeviceNet/Ethernet (TCP/IP)/CANopen

Product Description

The RVLF is the economical and compact AC variable frequency drive for use with 3-phase AC induction motors. The drives have compact dimensions and can be installed side by side to save space.

The full range of products

covers various voltage ratings: single-phase 100V or 200V, as well as, three-phase 200V or 480V.

The RVLF Advance comes with sensorless vector control as well as onboard BACnet and Modbus communication.

Specifications are stated at 40°C at 5kHz unless otherwise noted.

Ordering Key **RVLF A 1 20 075 F A**

Variflex ³ AC Drive	_____
Frame Size	_____
AC Supply	_____
Drive Voltage Rating	_____
Drive kW Rating	_____
Filter	_____
Advance	_____

Approvals



Type Selection

Frame Size	AC Supply Phase	Drive Voltage Rating	Drive kW Rating	Filter	Advance
A: Size 1 B: Size 2 C: Size 3 D: Size 4	1: 1-Phase 3: 3-Phase	10: 100-120VAC 20: 200-240VAC 40: 380-480VAC	040: 0.4kW, 0.5HP 075: 0.75kW, 1.0HP 150: 1.5kW, 2.0HP 220: 2.2kW, 3.0HP 370: 3.7kW, 5.0HP 550: 5.5kW, 7.5HP 750: 7.5kW, 10HP 1100: 11kW, 15HP	F: Built-in EMI filter	A: Advance



Selection Guide

Voltage Rating	AC Supply Phase	Motor Rating		Ordering Code
100 - 120VAC (+10% / -15%)	1-Phase	0.4kW	0.5HP	RVLFA110040A
		0.75kW	0.75HP	RVLFA110075A
200 - 240VAC (+10% / -15%)	1-Phase	0.4kW	0.5HP	RVLFA120040FA
		0.75kW	0.75HP	RVLFA120075FA
		1.5kW	2.0HP	RVLFB120150FA
		2.2kW	3.0HP	RVLFB120220FA
200-240VAC (+10%/-15%)	3 Phase	0.4kW	0.5HP	RVLFA320040A
		0.75kW	0.75HP	RVLFA320075A
		1.5kW	2.0HP	RVLFB320150A
		2.2kW	3.0HP	RVLFB320220A
380 - 480VAC (+10% / -15%)	3-Phase	0.75kW	0.75HP	RVLFB340075FA
		1.5kW	2.0HP	RVLFB340150FA
		2.2kW	3.0HP	RVLFB340220FA
		3.7kW	5.0HP	RVLFC340370FA
		5.5kW	7.5HP	RVLFC340550FA
		7.5kW	10HP	RVLFD340750FA
		11kW	15HP	RVLFD3401100FA

Input / Output Data

100V Class: Single phase

Model	RVLFA110040A	RVLFB110075A
Horse power rating	0.5HP	1HP
Nominal motor power	0.4kW	0.75kW
Rated output current	2.6A	4.3A
Rated capacity	1.00kVA	1.65kVA
Input voltage range	Single phase: 100~120VAC (+10% / -15%), 50/60Hz	
Output voltage range	Three phase 0~240VAC	
Input current	13A	19A
Allowable momentary power loss time	1.0 s	1.0 s
Ingress protection class	IP20	

200V Class: Single phase

Model	RVLFA120040FA	RVLFA120075FA	RVLFB120150FA	RVLFB120220FA
Horse power rating	0.5HP	1HP	2HP	3HP
Nominal motor power	0.4kW	0.75kW	1.5kW	2.2kW
Rated output current	2.6A	4.3A	7.5A	10.5A
Rated capacity	1.0kVA	1.65kVA	2.90kVA	4.0kVA
Input voltage range	Single phase: 200~240VAC (+10% / -15%), 50/60Hz			
Output voltage range	Three phase 0~240VAC			
Input current	7.2A	11A	15.5A	21A
Allowable momentary power loss time	1.0s	1.0s	2.0s	2.0s
Ingress protection class	IP20			



Input / Output Data cont.

200V Class: Three Phase

Model	RVLFA320040A	RVLFA320075A	RVLFB320150A	RVLFB320220A
Horse power rating	0.5HP	1HP	2HP	3HP
Nominal motor power	0.4kW	0.75kW	1.5kW	2.2kW
Rated output current	2.6A	4.3A	7.5A	10.5A
Rated capacity	1.0kVA	1.65kVA	2.90kVA	4.0kVA
Input voltage range	Three phase: 200~240VAC (+10% / -15%), 50/60Hz			
Output voltage range	Three phase 0~240VAC			
Input current	4A	6.4A	9.4A	12.2A
Allowable momentary power loss time	1.0s	1.0s	2.0s	2.0s
Ingress protection class	IP20			

400V Class: Three phase

Model	RVLFB340075FA	RVLFB340150FA	RVLFB340220FA	RVLFC340370FA
Horse power rating	1HP	2HP	3HP	5HP
Nominal motor power	0.75kW	1.5kW	2.2kW	3.7kW
Rated output current	2.3A	3.8A	5.2A	9.2A
Rated capacity	1.7kVA	2.9kVA	4.0kVA	7.0kVA
Input voltage range	Three phase: 380~480VAC (+10% / -15%), 50/60Hz			
Output voltage range	Three phase 0~480VAC			
Input current	4.2A	5.6A	7.3A	10.1A
Allowable momentary power loss time	2.0s	2.0s	2.0s	2.0s
Ingress protection class	IP20			

Model	RVLFC340550FA	RVLFD340750FA	RVLFD3401100FA
Horse power rating	7.5HP	10HP	15HP
Nominal motor power	5.5kW	7.5kW	11kW
Rated output current	13.0A	17.5A	24A
Rated capacity	9.91kVA	13.34kVA	18.29kVA
Input voltage range	Three phase: 380~480VAC (+10% / -15%), 50/60Hz		
Output voltage range	Three phase 0~480VAC		
Input current	14.3A	19.3A	26.4A
Allowable momentary power loss time	2.0s	2.0s	2.0s
Ingress protection class	IP20		

Environmental Data

Installation Location	Indoor (protected from corrosive gases and dust)	Shock and Vibration	0.075mm Amplitude for 10Hz to 57Hz 1G for 57Hz to 150Hz
Operating Temperature	-10~+50°C / -14 ~+122°F (De-rating from 40°C/10°F up to 50°C/122°F)	EMC Compliance	EN61800-3, first environment
Storage Temperature	-20~+60°C / -4 ~+140° F	LVD Compliance	EN61800-5-1
Humidity	Under 95% RH (no condensation)	Electrical Safety	UL508C
		Ingress Protection Level	IP20


General Data

Control Mode	V/F Control + SLV Control	Display	
Frequency		7 segment display (LED)	Display: parameter/ parameter value/frequency/ speed/DC voltage/ output voltage/output current/PID feedback/input and output terminal status/ heat sink temperature/ program version/fault log. For run/stop/forward and reverse.
Range	0.01 ~ 599Hz.		
Speed accuracy (100% torque)	V/F: 3% SLV: 1%		
Starting torque	V/F: 3Hz / 100% SLV: 3Hz / 150%		
Setting resolution	Digital input: 0.01Hz. Analog input: 0.015Hz/60Hz	LED status Indicator	
Setting	• Keypad: Set directly with ▲▼ keys or the VR (potentiometer) on the keypad. • External input terminals: AVI (0/2~10V), ACI (0/4~20mA) input. Multifunction input up/down function (Group3). • Setting frequency by communication method.		
Frequency limit	Lower and upper frequency limits, 3 skip-frequency settings.		
Run		Protection Functions	
Operational settings	• Keypad: run, stop button. • External terminals: Multi-operation-mode 2/3 wire selection. • Communication method.	Overload protection	Integrated motor and inverter overload protection. (150% rated current for 60sec, every 10 minutes)
		Over voltage	100V/200V models: Over 410VDC, 400V models: Over 820VDC.
		Under voltage	100V/200V models: Under 190VDC, 400V models: Under 380V.
		Momentary power loss restart	Inverter auto-restart after a momentary power loss.
		Stall prevention	Stall prevention for acceleration/deceleration/ and continuous run.
		Short-circuit output terminal	Electronic circuit protection.
		Grounding fault	Electronic circuit protection.
		Additional protective functions	Heatsink over temperature protection, auto carrier frequency reduction with temperature rise, fault output, reverse prohibit, number of auto restart attempts, parameter lock, over voltage protection (OVP), motor PTC over-temperature protection.
Drive Functions		Internation Certification	CE/cULUs
V/F curve setting	6 fixed curve and one customized curve. 1~16KHz (default 5KHz).	Communication	RS485 (Modbus) built in, with one-to-one or one-to-many control.
Carrier frequency Acceleration and deceleration control	2 Acc/Dec time parameters, 4 S curve parameters.		Built-in BacNet communication
Multifunctional input	19 functions (refer to description on group3).		
Multifunctional output	16 functions (refer to description on group3).		
Multifunctional analog output	5 functions (refer to description on group4). Overload detection, 8 preset speeds, Auto-run, Acc/Dec switch (2 stages), Main/Alt run command select, Main/Alt frequency command select, PID control, torque boost, V/F start frequency, fault reset.		
Main Features			

Connection Diagrams


Model: Single Phase (NPN)

100V: RVLFA110040A, RVLFA110075A



Model: Single Phase (PNP)


200V: RVLFA120040FA, RVLFA120075FA, RVLFB120150FA, RVLFB120220FA



Connection Diagrams cont.


Model: Three Phase (NPN)

200V: RVLFA320040A, RVLFA320075A, RVLFB320150A, RVLFB320220A



Model: Three Phase (PNP)


400V: RVLFB340075FA, RVLFB340150FA, RVLFB340220FA



Connection Diagrams cont.

Model: Three Phase (PNP/ NPN)

400V: RVLFC340370FA, RVLFC3405500FA, RVLFD340750FA, RVLFD3401100FA



NPN/PNP input type selection

- PNP:
1. Link SC and COM terminal
 2. Use +24v terminal for S1~S5 common point
- NPN:
1. Link SC and +24V terminal
 2. Use COM terminal for S1~S5 common point

Please ensure correct connection before setting parameter group3 digital inputs.


Terminal Description

Terminal symbol	TM1 Function description
L1(L)	Main power input, single phase: L1(L) / L3(N)
L2	three phase (200V): L1(L) / L2 / L3(N)
L3 (N)	three phase (400V): L1 / L2 / L3
P*	Externally connected braking resistor
BR*	
T1	
T2	Inverter output, connect to U, V, W terminals of motor
T3	
Ground	Ground terminal

* P, BR for three phase 400V models


Terminal Description cont.

Single phase (100V & 200V)




Note: the screw on L2 terminal is removed for the single phase input supply models

Three phase (200V)



Three phase (400V)




Frame A & Frame B


Terminal symbol	TM2 Function description	Signal Level
RA		
RB	Relay output terminal, specification: 250VAC/1A (30VDC/1A)	240VAC/1A (30VDC/1A)
COM	Voltage reference point for S1~S5	+/- 15%, Max output current 30mA
+24	S1~S5 (Common) [PNP]	
S1~S5	Multi-function input terminals (refer to group3)	24 VDC, 4.5 mA, optical coupling isolation (Max, voltage 30VDC, input impedance 6kΩ)
10V	Built in power for an external speed potentiometer	10V, (Max current:20mA)
AVI	Analog voltage input, Specification: 0/2~10VDC (choose by parameter 04-00)	0~10V (Input impedance 200kΩ)
ACI	Analog current input, Specification: 0/4~20mA (choose by parameter 04-00)	0~20mA (Input impedance 499Ω)
AO	Multi-function analog output terminal. Maximum output 10VDC/1mA	0~10V (Max current 2mA)
AGND	Analog ground terminal	

Terminal Description cont.

NPN:



PNP:




Frame C & Frame D

Terminal symbol	TM1 Function description
RA	
RB	Relay output terminal, specification: 250VAC/5A (30VDC/5A) RA: Normally open, RB: Normally close, RC: Common point
RC	


Terminal symbol	TM2 Function description	Signal Level
+24V	Common point of PNP input	
SC	NPN/PNP selectable terminal. NPN input: +24V&SC need to be shorted. PNP input: COM&SC need to be shorted.	+/- 15%, Max output current 30mA
COM	Voltage reference point for S1~S5	
S1~S5	Multi-function input terminals (refer to group3)	24 VDC, 4.5 mA, optical coupling isolation (Max, voltage 30VDC, input impedance 6kΩ)
10V	Built in power for an external speed potentiometer (Max output : 20mA)	10V, (Max current:20mA)
AVI / PTC	Analog voltage input/motor over temperature protection signal input, Specification: 0/2~10VDC	0~10V (Input impedance 200kΩ)
ACI	Analog current input, Specification: 0/4~20mA (choose by parameter 04-00)	0~20mA (Input impedance 499Ω)
AO	Multi-function analog output terminal. Maximum output 10VDC/1mA	0~10V (Max current 2mA)
AGND	Analog ground terminal	

NPN/PNP control terminals:




Dimensions (mm/inches)

Frame A




Frame B




Dimensions cont. (mm/inches)

Frame C



RVLFC	W	W1	H	H1	H2	H3	D	D1	D2	E	E1	E2	Weight kg (lbs)
340370FA	129/	118/	197.5/	177.6/	188/	154.7/	148/	143.7/	136/	102.6/	96/	48.2/	2.7 (5.95)
340550FA	5.08"	4.65"	7.78"	6.99"	7.4"	6.09"	5.83"	5.66"	5.35"	4.04"	3.78"	1.9"	

Frame D



RVLFD	W	W1	H	H1	H2	H3	D	D1	D2	E	E1	Weight kg (lbs)
340750FA	187/	176/	273/	249.8/	261/	228.6/	190/	185.6/	177.9/	136/	84.7/	
3401100FA	7.36"	6.93"	10.75"	9.83"	10.28"	9"	7.48"	7.31"	7"	5.35"	3.33"	6.3 (13.89)

Accessories

Communication Modules



TCP-IP Module

- Ordering Code: RV-TCP/IP
- Communication Protocol: TCP-IP



Profibus-DP Module

- Ordering Code: RV-PDP
- Communication Protocol: Profibus



CANopen Module

- Ordering Code: RV-CAN
- Communication Protocol: CANopen

Motor Controllers
AC Variable Frequency Drives
Type Variflex³ RVLF Advance



DeviceNet Module

- Ordering Code: RV-DNET
- Communication Protocol: DeviceNet



USB-to-RS485 Connection Cable

Type 1

- Ordering Code: RV-USB
- Cable Length: 1.8m

Type 2

- Ordering Code: RV-USB3
- Cable Length: 3.0m

Copy module



- Ordering Code: RV-CU
- Plug'n'play design
- Remote keypad
- Copy and Keypad functions

Copy module extension cable



Type 1

- Ordering Code: RV-CAB01
- Cable Length: 1.0m

Type 2

- Ordering Code: RV-CAB02
- Cable Length: 2.0m

Type 3

- Ordering Code: RV-CAB03
- Cable Length: 3.0m

Type 4

- Ordering Code: RV-CAB05
- Cable Length: 5.0m

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231

Архангельск (8182)63-90-72

Астрахань (8512)99-46-04

Барнаул (3852)73-04-60

Белгород (4722)40-23-64

Брянск (4832)59-03-52

Владивосток (423)249-28-31

Волгоград (844)278-03-48

Вологда (8172)26-41-59

Воронеж (473)204-51-73

Екатеринбург (343)384-55-89

Иваново (4932)77-34-06

Ижевск (3412)26-03-58

Иркутск (395)279-98-46

Россия (495)268-04-70

Казань (843)206-01-48

Калининград (4012)72-03-81

Калуга (4842)92-23-67

Кемерово (3842)65-04-62

Киров (8332)68-02-04

Краснодар (861)203-40-90

Красноярск (391)204-63-61

Курск (4712)77-13-04

Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13

Москва (495)268-04-70

Мурманск (8152)59-64-93

Набережные Челны (8552)20-53-41

Нижний Новгород (831)429-08-12

Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81

Новосибирск (383)227-86-73

Омск (3812)21-46-40

Орел (4862)44-53-42

Оренбург (3532)37-68-04

Пенза (8412)22-31-16

Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15

Рязань (4912)46-61-64

Самара (846)206-03-16

Санкт-Петербург (812)309-46-40

Саратов (845)249-38-78

Севастополь (8692)22-31-93

Симферополь (3652)67-13-56

Казахстан (7172)727-132

Смоленск (4812)29-41-54

Сочи (862)225-72-31

Ставрополь (8652)20-65-13

Сургут (3462)77-98-35

Тверь (4822)63-31-35

Томск (3822)98-41-53

Тула (4872)74-02-29

Тюмень (3452)66-21-18

Ульяновск (8422)24-23-59

Уфа (347)229-48-12

Хабаровск (4212)92-98-04

Челябинск (351)202-03-61

Череповец (8202)49-02-64

Ярославль (4852)69-52-93